


VS-1502 Wireless Vibration Sensor

1.Appearance



2.Features

VS-1502 vibration sensor has nice appearance, simple operation, easy to installed and strong applicability, can send out alarm signal accurately, as well as monitor violent acts effectively. Pulse counting can be adjustment.

3.Specifications


Model: VS-1502	Working Voltage: 3V
Working Environment: ~5°C ~50°C	Alarm: Vibration
Signal range : 30m radius	Working current:~ 10μA
Working frequency: 433MHz /868MHz	

4.Installation



- ① Open the front cover by ② Attach the base to the wall ③ Replace the cover pressing the tap as arrow.

5.Dip switch



Sensibility adjustment

level 1--Maximum sensibility SW-2 off SW-1 off
 (DEFAULTS)
 level 2--level 2 SW-2 on SW-1 off
 level 3--level 3 SW-2 off SW-1 on
 level 4--minimum sensibility SW-2 on SW-1 on

